

## INHIBITOR

## FOR CENTRAL HEATING SYSTEMS

## **DIRECTIONS FOR USE**

- 1. Shake well before use.
- 2. Turn off the boiler.
- 3. Use after the system has been flushed through with either Protex De-Scaler or Protex Universal Cleanser.
- 4. Add Protex Inhibitor directly into the expansion vessel or header tank as the system is being filled. If being added to an existing system, first drain off at least 6 litres of water.
- 5. Refill the system and turn on the boiler pump so that the mixture becomes evenly distributed through the radiator system.
- 6. Complete system treatment label and attach to filling point.
- 7. Use the self adhesive label to register date of application.

